

FLUKE®

931

Tachometer

Users Manual

English

PN 3409877
January 2009

© 2009 Fluke Corporation, All rights reserved. Printed in Germany.
Specifications are subject to change without notice. All product names are
trademarks of their respective companies.

LIMITED WARRANTY AND LIMITATION OF LIABILITY

Each Fluke product is warranted to be free from defects in material and workmanship under normal use and service. The warranty period is one year and begins on the date of shipment. Parts, product repairs, and services are warranted for 90 days. This warranty extends only to the original buyer or end-user customer of a Fluke authorized reseller, and does not apply to fuses, disposable batteries, or to any product which, in Fluke's opinion, has been misused, altered, neglected, contaminated, or damaged by accident or abnormal conditions of operation or handling. Fluke warrants that software will operate substantially in accordance with its functional specifications for 90 days and that it has been properly recorded on non-defective media. Fluke does not warrant that software will be error free or operate without interruption.

Fluke authorized resellers shall extend this warranty on new and unused products to end-user customers only but have no authority to extend a greater or different warranty on behalf of Fluke. Warranty support is available only if product is purchased through a Fluke authorized sales outlet or Buyer has paid the applicable international price. Fluke reserves the right to invoice Buyer for importation costs of repair/replacement parts when product purchased in one country is submitted for repair in another country.

Fluke's warranty obligation is limited, at Fluke's option, to refund of the purchase price, free of charge repair, or replacement of a defective product which is returned to a Fluke authorized service center within the warranty period.

To obtain warranty service, contact your nearest Fluke authorized service center to obtain return authorization information, then send the product to that service center, with a description of the difficulty, postage and insurance prepaid (FOB Destination). Fluke assumes no risk for damage in transit. Following warranty repair, the product will be returned to Buyer, transportation prepaid (FOB Destination). If Fluke determines that failure was caused by neglect, misuse, contamination, alteration, accident, or abnormal condition of operation or handling, including overvoltage failures caused by use outside the product's specified rating, or normal wear and tear of mechanical components, Fluke will provide an estimate of repair costs and obtain authorization before commencing the work. Following repair, the product will be returned to the Buyer transportation prepaid and the Buyer will be billed for the repair and return transportation charges (FOB Shipping Point).

THIS WARRANTY IS BUYER'S SOLE AND EXCLUSIVE REMEDY AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. FLUKE SHALL NOT BE LIABLE FOR ANY SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES OR LOSSES, INCLUDING LOSS OF DATA, ARISING FROM ANY CAUSE OR THEORY.


Since some countries or states do not allow limitation of the term of an implied warranty, or exclusion or limitation of incidental or consequential damages, the limitations and exclusions of this warranty may not apply to every buyer. If any provision of this Warranty is held invalid or unenforceable by a court or other decision-maker of competent jurisdiction, such holding will not affect the validity or enforceability of any other provision.

Fluke Corporation
P.O. Box 9090
Everett, WA
98206-9090
U.S.A.

Fluke Beijing Service Center
Rm. 401 SCITEC Tower
Jianguomenwai Dajie
Beijing 100004, PRC
Hot Line: 400.810.3435
Fax: (8610) 65286307

CONTENTS

Introduction.....	1
How to contact Fluke.....	1
Included Accessories.....	1
The Keypad.....	1
The Display	2
Operation	3
Configuration.....	3
Optical (Non-Contact).....	3
Contact	3
Surface Speed and Length	4
Contact Wheel Use	4
Max, Min and Av Readings	5
Replacing The batteries	5
Specifications.....	5
RPM.....	5



- | | |
|------------------------|-------------------|
| ① Mechanical Adapter | ⑥ Reflector Strip |
| ② Shaft Contacts | ⑦ Display |
| ③ Contact wheel 0.1 m | ⑧ Memory key |
| ④ Contact wheel 6 inch | ⑨ Function key |
| ⑤ Shaft Extension | ⑩ ON key |

INTRODUCTION

The Fluke 931 Tachometer (the Tachometer) is a hand-held instrument that accurately measures rotational Revolutions Per Minute (RPM) or surface speed as well as length. Non-contact RPM measurements can be made using the Infrared Beam function, or contact RPM measurements using the mechanical adapter and selectable tip. The Memory function allows storing the maximum (MAX), minimum (MIN), average (AV), and last reading.

HOW TO CONTACT FLUKE

To contact Fluke, call one of the telephone numbers that follow:

- Technical Support USA: 1-800-99-FLUKE (1-800-993-5853)
- Calibration/Repair USA: 1-888-99-FLUKE (1-888-993-5853)
- Canada: 1-800-36-FLUKE (1-800-363-5853)
- Europe: +31 402-675-200
- Japan: +81-3-3434-0181
- Singapore: +65-738-5655
- Anywhere in the world: +1-425-446-5500

Or, visit Fluke's website at <http://www.fluke.com.cn>.




To register your product, visit <http://register.fluke.com>.

INCLUDED ACCESSORIES


The following accessories are included with the Tachometer:

- 0.1 m Contact Wheel
- 6 in Contact Wheel
- Cone Shaft Contact
- Internal Cone Shaft Contact
- Shaft Extension
- 10 Reflective Strips

THE KEYPAD


Key	Description
	Selects MAX, MIN, AV, and last reading
	Turns the Tachometer ON and makes selections. The Tachometer turns OFF after 30 seconds of inactivity.
	Selects the Measurement function

THE DISPLAY



Item	Description
①	Optical RPM measurement
②	Contact RPM measurement
③	Meters per minute
④	Meters per second
⑤	Feet per minute
⑥	Feet per second
⑦	Inches per minute
⑧	Trigger display
⑨	Memory, last stored reading
⑩	Memory, maximum reading
⑪	Memory, minimum reading
⑫	Memory, average reading
⑬	Low battery indicator
⑭	Numerical reading




OPERATION

Press  to power up the Tachometer. The display test illuminates all LCD segments for 1 second and then shows the configured surface speed selection.

- The last selected mode appears at when the Tachometer is turned ON.
- The Tachometer automatically turns OFF after 30 seconds of inactivity.



CONFIGURATION

To configure the Tachometer for the correct contact wheel used for surface speed measurements:

1. Turn the Tachometer ON.
2. Press  and  release.
3. Use  to select 0.1 (0.1 m circumference small wheel) or 6" (6 inch circumference large wheel). A 12" wheel is not available.




OPTICAL (NON-CONTACT)

To measure RPM using the non-contact infrared beam, remove the mechanical adapter from the top of Tachometer. Pull the adapter straight out to remove. See Figure 2.

1. Stop the rotating device to measure.
2. Clean a spot for the reflective strip.
3. Place reflective strip on rotating device.
4. Turn the Tachometer ON and use  to select RPM.
5. Aim Tachometer at rotating reflective strip keeping within 500 mm (20 inches).
6. Press  to enable the infrared beam.
7. When the Tachometer is triggered by the reflective strip, the trigger symbol on the display flashes and RPM will be displayed.

CONTACT

To use the Tachometer for contact measurement, insert the mechanical adapter into top of the Tachometer, see Figure 1:

1. To measure, connect the cone or internal cone shaft contact to the end of the shaft.
2. Turn the Tachometer ON and use  to select RPM .
3. Press  to take measurements.
4. When the Tachometer is triggered, the trigger symbol flashes and the RPM is displayed.

SURFACE SPEED AND LENGTH

Surface speed and length can be measured using the mechanical adapter and contact wheel.

	Range	
	0.1 m	6 "
m/min	0.10 to 1999	0.10 to 1524
ft/min	0.40 to 6550	0.40 to 5000
in/min	4.0 to 78700	4.00 to 60000
m/sec	0.10 to 33.30	0.10 to 25.40
ft/sec	0.10 to 109	0.10 to 83.33
m	0 to 99999	
ft	0 to 99999	
in	0 to 99999	

CONTACT WHEEL USE

1. Insert mechanical adapter into the top of the Tachometer. See Figure 1.
2. Select either the 0.1 m or 6 inch contact wheel to use.
3. Set the Tachometer to 0.1 or 6 inch setting for the contact wheel in use.
4. Use **[FUNC]** to select units of measure.
5. Contact wheel to surface to measure and press **[M]** to take measurements.
6. When the Tachometer is triggered, the trigger symbol flashes and the measurement is displayed.

MAX, MIN AND AV READINGS

Press **[MEM]** to enable MAX, MIN and AV readings stored in memory. Each time a new measurement is taken, the maximum, minimum, average and last value are stored. The last value is shown under MEM. The units of measure for the stored readings will also be displayed. Press **[M]** to exit the memory display mode.

REPLACING THE BATTERIES

Replace the batteries when LOBAT appears on display. See Figure 3.

1. Remove the battery cover on back of the Tachometer.
2. Replace with 2 AA 1.5V LR6 (Alkaline) batteries.
3. Replace the battery cover.

SPECIFICATIONS




RPM

	Range
Optical (non-contact)	1 to 99999 RPM
Contact	1 to 19999 RPM

Accuracy	±0.02 % of reading + 1 digit
Sensing Distance (optical)	500 mm (20 inches)
Battery Type	(2) AA 1.5 V LR6 (Alkaline)
Battery Life	approximately 40 hours
Operating Temperature	0 to +50 °C (32 to 122 °F)
Storage Temperature	-20 to +70 °C (0 to 160 °F)
Weight	250 g (0.55 lbs)
Size	175 x 60 x 28 mm (7 x 2.5 x 1 inch)

Note: Serial number of the Tachometer is located in battery compartment.

1 Handling



2 RPM /

rpm
8.8.8.8.8

RPM


1.00 - 99999 rpm



rpm 
8.8.8.8.8

RPM

0, 10 - 19999 rpm



3  / BATT

